



## Material data sheet – FlexLine

---

### EOS StainlessSteel 316L

EOS StainlessSteel 316L is a corrosion resistant iron based alloy which has been optimized for processing on EOS DMLS systems.

This document provides information and data for parts built using EOS StainlessSteel 316L powder (EOS art.-no. 9011-0032) on the following system specifications:

- Machine: EOS M100
- Powder: EOS StainlessSteel 316L
- Process: 316L 20µm FlexLine
- Software: EOSPRINT v1.3 & EOSYSTEM 1.5.3 - 35713

### Description

The parts built from EOS StainlessSteel 316L have chemical composition corresponding to ASTM F138 "Standard Specification for Wrought 18Cr-14Ni-2.5Mo Stainless Steel Bar and Wire for Surgical Implants (UNS S31673)". This kind of stainless steel is characterized having a good corrosion resistance and evidence that there are no leachable substances in cytotoxic concentrations.

This material is ideal in:

- Lifestyle/Consumer, e.g. watches, other jewellery, spectacle frames, decorations
- Automotive/Industrial
- Food and chemical plants; e.g. non-corroding common material
- Aerospace/Turbine industry
- Entry-level material for Laser Sintering Technology, e.g. mounting parts, heat exchangers, functional elements in electronic housing and accessories.

Parts built from EOS StainlessSteel 316L can be machined, shot-peened and polished in as-built or stress relieved (AMS 2759) states if required. Solution annealing is not necessary because the mechanical properties of as-built state are showing desired values (ASTM A403). Parts are not ideal in temperature range 427°C – 816°C where precipitation of chromium carbides occurs. Due to layer-wise building method, the parts have a certain anisotropy which could be seen from mechanical properties.



## Material data sheet – FlexLine

### Technical Data

#### Powder properties

Material composition	Element	Min	Max
	Fe	Balance	
	Cr	17.00	19.00
	Ni	13.00	15.00
	Mo	2.25	3.00
	C	-	0.030
	Mn	-	2.00
	Cu	-	0.50
	P	-	0.025
	S	-	0.010
	Si	-	0.75
	N	-	0.10

#### Max. particle size

Particles $\geq 53\mu\text{m}$ [1]	max. $\leq 5.5$ wt.-%
------------------------------------	-----------------------

[1] Analysis according to ASTM B214.

## Material data sheet – FlexLine

### General process data

Layer thickness	20 $\mu\text{m}$
Volume rate [2]	1.16 $\text{mm}^3/\text{s}$ (4.17 $\text{cm}^3/\text{h}$ )

[2] The volume rate is a measure of build speed during laser exposure of the skin area. The total build speed depends on this volume rate and many other factors such as exposure parameters of contours, supports, up and downskin, recoating time, Home-In or LPM settings.

### Physical and chemical properties of parts

Part density [3]	7.98 $\text{g}/\text{cm}^3$
Surface roughness after shot peening [4]	$R_a < 12 \mu\text{m}$ ; $R_z < 62 \mu\text{m}$

[3] Weighing in air and water according to ISO 3369.

[4] Measurement according to ISO 4287. The numbers were measured at the horizontal (up-facing) and all vertical surfaces of test cubes. Due to the layerwise building the roughness strongly depends on the orientation of the surface, for example sloping and curved surfaces exhibit a stair-step effect.

### Tensile data at room temperature [5, 6]

	As built
Ultimate tensile strength, $R_m$	625 MPa
Yield strength, $R_{p0.2}$	535 MPa
Elongation at break A	46 %

[5] The numbers are average values of vertical and horizontal orientation.

[6] Tensile testing according to ISO 6892 & ASTM E8M, proportional test pieces, diameter of the neck area 4 mm, original gauge length 4D (16 mm).



## Material data sheet – FlexLine

---

### Abbreviations

min. minimum  
max. maximum  
wt. weight

### Legal notes

The quoted values refer to the use of this material with above specified EOS DMLS system, EOSYSTEM software version, parameter set and operation in compliance with parameter sheet and operating instructions. All measured values are average numbers. Part properties are measured with specified measurement methods using defined test geometries and procedures and. Further details of the test procedures used by EOS are available on request. Any deviation from these standard settings may affect the measured properties.

The data correspond to EOS knowledge and experience at the time of publication and they are subject to change without notice as part of EOS' continuous development and improvement processes. EOS does not warrant any properties or fitness for a specific purpose, unless explicitly agreed upon. This also applies regarding any rights of protection as well as laws and regulations

EOS<sup>®</sup>, EOSINT<sup>®</sup>, DMLS<sup>®</sup>, DirectTool<sup>®</sup> and DirectPart<sup>®</sup> are registered trademarks of EOS GmbH

©2016 EOS GmbH – Electro Optical Systems. All rights reserved.